




Wash & Cure 3 Plus

Installation and Usage Instructions



Dear customer,

Thank you for choosing Anycubic products.

Please read this instruction carefully. The installation techniques and precautions in the instruction can help you avoid any unnecessary damage or frustration.

Please visit <https://support.anycubic.com> to contact us if you have any questions. To gain more information such as software, videos and models, you can visit Anycubic Wiki.



Anycubic support center



Anycubic Wiki

Safety Instructions

Always follow the safety instructions during assembly and usage, to avoid unnecessary damage to the machine or individual injury.

-  Please contact our Customer Service if you have any issues after receiving the products.
-  In the curing mode, do not take off the anti-UV cover to prevent potential hazard of UV light. Please wear protective glasses when FlexiCure is on without the cover.
-  In case of emergency, please immediately cut off the power of the machine and contact our technical support.
-  Keep the machine and its accessories out of the reach of children.
-  Be cautious when using the scraper. Never direct the scraper towards your hands.
-  The machine includes moving parts that can cause injury.
-  Do not clean the models directly without putting them in the washing basket or on the washing rack. After cleaning, the models need air-dried before curing.
-  The washing solvent should be sealed and stored in a cool and dry place after use. If the solvent is alcohol, please comply with usage specifications of alcohol.
-  Use the machine in an environment with a temperature of 10°C-40°C and a humidity of 20%-90%. For optimal performance, do not exceed this range.
-  Do not expose the machine to any water or rain environment.
-  Do not disassemble the machine, please contact the technical support if you have any questions.

Content

01	Introduction	1
-----------	---------------------	---

02	Control Panel	3
-----------	----------------------	---

03	Preparations	3
-----------	---------------------	---

04	Usage Instrution	4
-----------	-------------------------	---

	Wash Mode	4
--	-----------	---

	Cure Mode	6
--	-----------	---


	FlexiCure	8
--	-----------	---

05	Maintenance	10
-----------	--------------------	----


06	Troubleshooting	12
-----------	------------------------	----

01 Introduction

Overview



- 1. Anti-UV cover:** blocks 99.995% of UV light and plays a protective role
- 2. Control Panel:** ① to set work mode and time
② turn on/off FlexiCure
- 3. UV LED panel:** for model curing
- 4. Gooseneck light:** to cure the detail or some corners of the models




- 5. Power switch:** turn on/off the machine
- 6. Cover sensor:** to check whether the cover is on
- 7. Power socket:** to connect the external adapter

*UV light tester: Linshang LS125 UV LIGHT METER

In the Box



Wash & Cure 3 Plus



Washing bucket*1




Washing basket*1



Rack bar* 4



Curing table



Gooseneck light



Hex key set



User manual*1



Power adaptor

Product Parameters


Technical Specifications

Properties	Wash and Cure
Control method	Touch Panel
Rated Power	36W
Input Voltage	AC110-240V 50/60Hz
UV wavelength	405nm

Physical Dimensions

Product Dimension	312 mm(L) *267 mm(W) *434 mm (H)
Washing Volume	230 mm(L) *140 mm(W) *260 mm(H)
Curing Volume	210 mm(D) *260 mm(H)
Weight	5.7 kg

02 Control Panel



1. Wash Mode: To select wash mode. The rotor changes rotation direction every 2 minutes in the washing process.

2. Cure Mode: To select cure mode.

3. Start/Pause: Click to start/pause the process.

4. FlexiCure: Turn on/off gooseneck light. It can be used singly or help to cure some corners in cure mode. *FlexiCure cannot be enabled in wash mode.*



5. Reduce Time

6. Remaining Time: The remaining time of the process.

7. Add Time

03 Preparations

Take out the accessories in the machine.
Plug in power and turn on the machine.




04 Usage Instruction


Wash Mode

1. Place the printed objects. There are two cases to place, please choose according to the requirements.


① Place with the platform (height of the object on higher layer $\leq 250\text{mm}$ / on lower layer $\leq 150\text{mm}$)




Choose the positions to install the racks according to the platform size and model height





Snap one end of the rack



Slightly pull the two sides of the basket closer, snap into the other end of the rack




Turn the wider side upward




 It is recommended that the models smaller than 3 mm or with several tinny parts be washed with the print platform.

② Place the printed objects singly in the washing basket (height of the object $\leq 260\text{mm}$)



2. Pour the detergent* into the washing bucket. Then, place the bucket on the base.




Cover the lid

Align with the position line

*The washing solvent can be ethanol(95%) , detergent solution, etc..
The solvent cannot exceed the maximum scale.

3. Press Wash button to select this mode. You can modify the washing time by pressing +/– button. Then, press Start/Pause button to start the washing process. If the washing has to be paused, press the Start/Pause button.





4. A beeping sound indicates the process is finished. Please air dry the objects before curing. After washing, please cover the lid and remove the washing bucket to avoid spilling the washing solvent.

Cure Mode

1. Place the printed objects.


There are two cases to place, please choose according to the personal requirements.

① Single Layer




Put on the cover


② Double Layers (height of the object on higher layer $\leq 100\text{mm}$ / on lower layer $\leq 80\text{mm}$)



Assembly the curing table



Place the models



Put on the cover

2. Press Cure button to select this mode. You can modify the curing time by pressing + / - button. Then, press Start/Pause button to start the curing process. If the curing has to be paused, press the Start/Pause button.




 The curing will pause if the cover is removed. Do not remove the cover in the curing process to ensure the curing effect.

3. A beeping sound indicates the process is finished. If the machine is not used at this time, please cut off the power. If it is continuously cured for a long time, the temperature of UV LED panel may be high. Do not touch the panel after curing.

Flexicure


FlexiCure can be used singly to cure small printed objects or model details; it also helps to cure some dead corners. Insert the gooseneck light into the USB port before use it.

Supplementary curing: Adjust the gooseneck light to a proper position to cure where the LED panel cannot illuminate.




01

Adjust the position




02

Put on the cover



03

Select the cure mode




04

Set the time



05


Start the curing




06

Click to turn on/off FlexiCure

Cure singly: Please wear the protective glasses to avoid the injury to eyes.



Click to turn on/off FlexiCure



Cure the objects manually



Notice: 1. FlexiCure cannot be enabled in wash mode.



2. When the FlexiCure is used for 30 minutes, the protection mechanism of the machine will be triggered to turn it off.

05 Maintenance

Recycling of detergent

The solvent in the washing bucket might become muddy after long-time washing. The solvent can be recycled through the following treatment. It is recommended to dispose or replace the solvent after washing 30 models to ensure the washing effect.


- 1. Allow the washing solvent stay still for over 10 hours so the residue could be precipitated and settled.**
- 2. Filter the top layer of solvent and pour it into another container. Then, seal the container.**
- 3. Expose the residue in the sunlight. Then, the cured resin can be handled as general solid waste.**



Clean the rotor

The rotor may rotate abnormally after long-term use, you can remove the rotor from washing bucket to clean it. Please take off the washing bucket from the base and drain the solvent before cleaning.

1. Remove the rotor from the bottom of bucket and then clean it.



2. Install the rotor to the bottom of the bucket.

1. The machine does not work.

- Poor power contact. Pull out the power cord and plug it in again.
- The anti-UV cover is removed in the curing process. Please put on the cover.

2. The rotor inside the washing bucket does not rotate during the washing process.

- The rotor is stuck by foreign matter. Stop washing, pour out the solvent and remove the foreign matter.
- There are too much precipitation in the washing solvent. Stop washing, drain the solvent and clean the precipitation.

3. The machine has abnormal sound during operation.

- The ground where the machine is placed is not flat enough.
- The screw on the rotor is loose. Tighten the screw.

4. Part of print objects are white after wash and cure.

- The printed objects are cured immediately after washing. Please air dry them before curing.
- The concentration of the alcohol which is used for washing is not high enough. Use alcohol with concentration exceeding 95%.

5. The mode lights are not lit when you touch the mode button.

- Try again or reboot the machine.

Radio interference

WARNING: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Name: Lienco SAS
Add: 8 Rue Marcel Cerdan, 77600, Bussy Saint Georges, France
Contact: Ruoyu ZHANG
Tel: 0033766929910
E-mail: contact@lienco.eu



Name: WSJ PRODUCT LTD
Add: Unit 1, Alsop Arcade, Brownlow Hill, Liverpool L3 5TX
Contact: Michael
Tel: +44 1519470193
E-mail: info@wsj-product.com



品名: 清洗机/Wash&Cure

检验员: 

出厂日期:

执行标准: GB 4706.1

深圳市纵维立方科技有限公司

地址: 广东省深圳市龙岗区园山街道银荷社区
银海工业城11号厂房

Thank you for purchasing Anycubic products! Please visit Anycubic support center (support.anycubic.com/en) to report any issues with Anycubic products. Our professional after-sale service team would respond within 24 hours and solve the issues.



M02010183